

- 1. CONCRETE SHALL BE 3000 P.S.I.
- 2. REINFORCING BARS SHALL BE DEFORMED, AND TIED TOGETHER.
- 3. TRENCH BOTTOM WIDTH IN VICINITY OF THRUST BLOCK(S) INSTALLATION SHALL BE THE MINIMUM WIDTH.
- 4. BACKFILL AND COMPACT IN 6" LAYERS.
- 5. PLACE THRUST COLLAR ON ONE FULL JOINT OF PIPE.
- 6. LAST JOINT OF PIPE WITH THRUST COLLAR TO BE MECHANICAL JOINT PIPE.
- 7. PLACE MEG-A-LUG 4' FROM PLUG END OF PIPE.

